



Site Name	AMC 4209 CONYERS GA		Ticket	596277
Site Contact			Scheduled Date/Time	09/17/20 10:00:00 AM
Site Address	1536 DOGWOOD DR SE		OSBT Contact	Janie Smith
Site Address			Work Order Sent	September 14, 2020 09:12 AM
City	CONYERS		Site Phone:	
State, Zip	Georgia	30013	Please confirm scheduled date and time within 24 hours of receipt.	

**OSBT Ticket #: 596277**

**OSBT Customer: Windstream Pro Services - AMC**

**Customer Reference # 7687905**

**Technician MUST call the OSBT Call Center @ 713-895-1794 or 713-895-1799 Upon Arrival, and Completion. If you are going to be late to this service call for any reason, you must call the OSBT Call Center to notify prior to the scheduled arrival time. Failure to abide by this instruction will result in a deduction from pay awarded for this service call.**

**OSBT is now using an automated confirmations system (ACS) to confirm your service appointments 24-48 hours in advance. Please save as a contact and answer calls from 832-782-6177 to confirm your events and avoid duplicate phone calls.**

**By accepting this work order as a contractor of OneSource Building Technologies you are agreeing to the following list of assumptions. Your failure to comply with these items may result in reduction in payment or non-payment.**

- You will arrive on site on the correct date and time specified above.
- You will be qualified to complete the work described in the scope of work below
- You will all of the tools listed on this work order to complete the scope of work.
- You will submit all collateral required for this service within 24 hours
- After completion of this service call you will receive a billing receipt that you may approve for payment.

### Scope of Work:

Scheduled for 09/17/20 10:00:00 AM

Standard business hours are 8am to 6pm local time.

Check in/out with OSBT call center 713-895-1794 or (888) 787-8324 (toll free)

**\*\*BEFORE AND AFTER PHOTOS OF INSTALL REQUIRED\*\***

ADTRAN/CISCO CONSOLE CABLES ARE MANDATORY FOR THE TECH TO HAVE.

UNSUCCESSFUL SITES DUE TO TECH NOT BEING PREPARED WILL RESULT IN NON-PAYMENT.

\*\*\*Those without the Adtran/Cisco console cable can still console in using a male or female DB-9 connector (tech needs to have both) and the Cisco console cable.\*\*\*

CALL CENTER WILL TRANSER TECH TO SCHEDULED BRIDGE

**\*\*Any work asked to be performed which is out of scope is to be reported to the OSBT project coordinator immediately. This includes, but is not limited to: Wiring greater than 200 feet, extensions between two separate buildings, work on a ceiling with a height greater than 12 feet. Please see your specific work order or contact the project coordinator for any work that you question being in scope. Failure to advise of out of scope work can result in deduction of pay.\*\***

**\*\* Equipment shipped to the tech for the purpose of completing a dispatch must be shipped back within 24 hours of the tech leaving site. (Example PRI TESTER). If for any reason you are not able to ship the equipment back within the time allotted, contact the project coordinator immediately. Failure to do so can result in nonpayment.\*\***

1. If there are any issues causing delays please report them immediately to OneSource by calling the callcenter at 888-787-8324
2. Note that any out of scope work MUST be approved beforehand by a OneSource Project Coordinator. If the out of scope work is not preapproved it may be non-billable.
3. Do not rent or purchase any material or equipment without approval from a OneSource Project Coordinator. Doing so without approval may result in denial of reimbursement for costs incurred.

A. note that the onsite customer and customer phone support are not authorized to give approval, the approval MUST come from OneSource.

4. You must follow the scope and timeline for this work. If anything falls outside of the quoted cost or the expected timeframe onsite it MUST be escalated immediately to OneSource for approval.

5. If there are any safety concerns please escalate immediately to OneSource before proceeding.

#### SCOPE OF WORK:

Site Name:AMC 4209 CONYERS GA

Address info: 1536 DOGWOOD DR SE

LCON info: TBD

FIELD TECH TO CALL FOR SERVICE ACTIVATIONS : 8883716896

\*\*\*\*\*SOW OF WORK DESCRIPTION\*\*\*\*\*

\*\*\*\*\* PLEASE NOTE THAT THIS DISPATCH IS TO EXTEND THE PRIMARY ETHERENT CIRCUIT AND INSTALL CPE FOR THE PRIMARY ETHERNET ACCESS CIRCUIT AT THIS SITE. CIRCUIT TO BE EXTENDED FROM THE DEMARC TO THE MDF AND CPE TO BE TESTED WITH DATA ACTIVATIONS

FIELD TECH TO COMPLETE EXTENSION AND INSTALL/TEST WITH ACTIVATIONS

PERMANENT ACCESS - ORDER # 7687905

UNI ECCKT : 38/KQGN/639436//SB

DEMARC LOC: 2ND FLR TELCO RM 3903 PORT 1 ELEC TAG D DEMARC LOC Continued:

EQUIPMENT: Adtran 3448

ADTRAN SHIPPING INFORMATION:

- SHIPPED TO LOCATION
- FEDEX TRACKING 116987851479
- DELIVERED 3/06/2020
- Signed for by: AACKASON

DO NOT REMOVE ANY OF THE SERVICES THAT CUSTOMER IS INSTALLED ON AT THIS PREINSTALL  
A SEPARATE DATE WILL BE SCHEDULED FOR THE CONVERSION OF SERVICE

Technician must introduce himself as a representative of Windstream Business to end users on site.

\*\*\*\*\*VERY IMPORTANT\*\*\*\*\*

IT IS IMPERATIVE THAT YOU MAINTAIN THE HIGHEST LEVEL OF PROFESSIONALISM AND PATIENCE WHILE WORKING WITH WINDSTREAM AND THE END USERS.

IF THERE ARE ANY ISSUES ONSITE WITH THE CUSTOMER STOP AND ESCALATE TO YOUR OSBT PC IMMEDIATELY.

\*\*\*\*\*

Standard business hours are 8am to 5pm local time.

Escalation path:

(713) 895-1794 for OSBT Call Center (must call to check in/out on all orders)

(866) 333-3475 for OSBT Call Center (toll free)

#### MATERIAL LIST:

- Cat5 Cable (min 300 ft)
- Small Parts - RJ-45 Couplers and Connectors, RJ-11 Connectors, Mounting Equipment (Rack Nuts and Screws), Biscuit Jacks
- 8' Ladder
- Hand tools – Pliers, Multi-Tool, Flashlight, Power drill, LONG drill bits, masonry bits, A general-purpose drill bit set, and a hole-saw, Crimpers, Punch down Tool, Wire Strippers, Screwdrivers (Phillips and Flathead), Tape Measure, Sheetrock Saw, Utility Knife, Torx (Star-shaped) Bits. Fish Tape and/or Glow Rods, LED Headlight.
- Cleaning tools - Compressed air can, Velcro, Tie-Wraps, Magnets, Small Broom or Vacuum
- Diagnostic tools – Multimeter, Loop back plug.
- Buttset
- Toner and Wand

Technician must introduce himself as a representative of Windstream Business to end users on site.

\*\*\*\*\*VERY IMPORTANT\*\*\*\*\*

IT IS IMPERATIVE THAT YOU MAINTAIN THE HIGHEST LEVEL OF PROFESSIONALISM AND PATIENCE WHILE WORKING WITH WINDSTREAM AND THE END USERS.

IF THERE ARE ANY ISSUES ONSITE WITH THE CUSTOMER STOP AND ESCALATE TO YOUR OSBT PC IMMEDIATELY.

\*\*\*\*\*

Standard business hours are 8am to 5pm local time.

Escalation path:

(713) 895-1794 for OSBT Call Center (must call to check in/out on all orders)

(866) 333-3475 for OSBT Call Center (toll free)

**MATERIAL LIST:**

- Cat5 Cable (min 300 ft)
- Small Parts - RJ-45 Couplers and Connectors, RJ-11 Connectors, Mounting Equipment (Rack Nuts and Screws), Biscuit Jacks
- 8' Ladder
- Hand tools – Pliers, Multi-Tool, Flashlight, Power drill, LONG drill bits, masonry bits, A general-purpose drill bit set, and a hole-saw, Crimpers, Punch down Tool, Wire Strippers, Screwdrivers (Phillips and Flathead), Tape Measure, Sheetrock Saw, Utility Knife, Torx (Star-shaped) Bits. Fish Tape and/or Glow Rods, LED Headlight.
- Cleaning tools - Compressed air can, Velcro, Tie-Wraps, Magnets, Small Broom or Vacuum
- Diagnostic tools – Multimeter, Loop back plug.
- Buttset
- Toner and Wand

**TOOL LIST:**

- Laptop with Windows 7 or Later Operating System
- Microsoft Office
- TeamViewer 14
- Cisco / ADTRAN Console Cable (USB to DB9)
- Mobile Hotspot
- Modular Adapters
- Spare Power strip
- Digital Camera /High end Smartphone
- Label Maker

**Collateral Requirement:**

- Before and after install photos – Including images of installed/tested devices
- Testing results
- Speed Test (If applicable)
- Signed OSBT work order (Service Acknowledgement Disclaimer page) and
- OSBT sign off – with MOD signature

All collateral must be submitted within 24 hours of completing the service call.

**TOOL LIST:**

- Laptop with Windows 7 or Later Operating System
- Microsoft Office
- TeamViewer 14
- Cisco / ADTRAN Console Cable (USB to DB9)
- Mobile Hotspot
- Modular Adapters
- Spare Power strip
- Digital Camera /High end Smartphone
- Label Maker

**Collateral Requirement:**

- Before and after install photos – Including images of installed/tested devices
- Testing results
- Speed Test (If applicable)
- Signed OSBT work order (Service Acknowledgement Disclaimer page) and
- OSBT sign off – with MOD signature

All collateral must be submitted within 24 hours of completing the service call.

Site Name	AMC 4209 CONYERS GA	Ticket	596277
Site Contact		Scheduled Date/Time	09/17/20 10:00:00 AM
Site Address	1536 DOGWOOD DR SE	OSBT Contact	Janie Smith
Site Address		Work Order Sent	September 14, 2020 09:12 AM
City	CONYERS	Site Phone:	
State Zip	Georgia	30013	Please confirm scheduled date and time within 24 hours of receipt.

**The following must be completed and faxed to 832-782-6199 (US and International)  
or 888-482-6199 (US Only) before leaving site.  
All additional collateral must be submitted to collateral@osbt.com**

Technician Name:		Travel Time:		Arrival Time:	
Technician Phone:		Miles Driven:		Departure Time:	

**Please describe work completed onsite:**

***For Emergencies please contact the  
OSBT Safety Team at:  
1-866-648-3949***

		Technician Signature:	
Customer Name:	Customer Signature:	Date:	

### Stop Work Clause:

- If, while onsite, it is requested that you do anything outside of the original scope, contact your coordinator immediately or risk not being compensated for the job. All direction must come from OSBT, unless explicitly stated in the work order.
  - If you are unreachable during the reconfirmation window causing OSBT to exhaust time and resources to recover and/or reschedule a service ticket, the ticket is non-payable.
  - If you did not speak with anyone at OSBT, and were NOT asked to proceed to site, you may not show up and expect to complete the work or be paid.

### Fit for Duty/Fatigue Management Policy:


- Any employee (or contractor) working 8+ hours should be allotted a 1-hour lunch break – this is not required and can be used at your discretion with proper communication with your PC/PM.
- Per OSBT's Fit for Duty SP-035-02:
  - Fatigue management is always a requirement whenever working on client sites. Worker fatigue can be a factor in incidents or risk to personnel. Therefore, we must ensure that:
    - Contractors report to work rested to prevent fatigue during a planned work schedule for that day.
    - Work shall be planned such that no one is scheduled to work for more than 14 continuous hours, including breaks and meal times (two consecutive shifts), and travel to/from the site.
    - As soon a subcontractor recognizes that they may exceed 14 continuous hours of work, you must request an extension from your assigned PC or PM.
    - OSBT and its subcontractors monitor activities, pay close attention to critical tasks and behavior to determine if an employee/subcontractor should be removed from the work site to obtain rest, or should be given a rest period upon arriving at the work site before beginning work.

### Incident Reporting | Proper Protocol Reminder:

- Please do not forget that any incident resulting in injury, illness, and/or damage to OSBT, equipment vendor or customer tools/equipment while in the office or on a customer site, must be reported. This is especially true for any incident where medical treatment is required. By law, we are required to complete and file incident reports for these instances.
- If you experience any of the above while onsite, please complete the [OSBT Incident Reporting Form](#) and immediately engage your assigned PC/PM.

### T1 Loopback Plug:

- **Materials**
  - Unused RJ45 male mod plug
  - Two strands (one pair) of category 5 wire (approximately two inches in length)
  - RJ45 crimp tool
- **Method**
  - Insert one end of wire 1 into Pin 1 of the RJ45 connector.
    - Note: To ensure a good connection, make sure that each wire goes all the way into the end of the plug.
    - Refer to drawing on the left for RJ45 pin layout.
  - Insert the other end of wire 1 into Pin 4 of the RJ45 connector.
  - Insert one end of wire 2 into Pin 2 of the RJ45 connector.
  - Insert the other end of wire 2 into Pin 5 of the RJ45 connector.
  - Crimp the connector.



## **COVID-19 Safety Measures:**

- If you have traveled internationally within the last 28 days, please make us aware of this prior to accepting this assignment
- If anyone living in your home including housemates, family members, or friends have traveled internationally within the last 28 days please make us aware of this prior to accepting this assignment
- If you, or anyone you've come in contact with, has a respiratory illness or a fever greater than 100.4° F please refrain from work and remain home until cleared by a medical doctor
- Please ensure to cover your noses and mouths with a tissue when coughing or sneezing (or an elbow or shoulder if no tissue is available)
- Please wash your hands with soap and water as frequently as possible / reasonable
- Purell and other alcohol-based hand sanitizers are not 100% effective at killing viruses, specifically COVID-19
- Make use of disinfectant wipes on tools, electronics, cell phones and steering wheels.
- It is recommended that all partners do everything they can to limit the touching of their faces.
- Bleach and chlorinated wipes are effective at killing viruses including COVID-19
- Travel with gloves and face masks, in case asked by a customer to wear these items
- Some customer sites may require, upon arrival, temperature checks to verify a temperature of 100.4 or lower
- Practice SOCIAL DISTANCING while on-site:
  - Refrain from shaking hands or touching others, greet verbally, with a wave, head nod, or some other appropriate professional gesture
  - Be mindful of physical space – attempt to maintain at least 6 feet away from others
- PROPER FACE COVERING - CDC: Use of Cloth Face Coverings to Help Slow the Spread of COVID-19
  - <https://www.cdc.gov/coronavirus/2019-ncov/prevent-getting-sick/diy-cloth-face-coverings.html>
  - Published by the CDC and reviews:
    - How to Wear/Remove a Cloth Face Covering
    - How to Clean/Sterilize a Cloth Face Covering
    - How to Make a Suitable Cloth Face Covering
- PROPER FACE COVERING – Fabrics Which are Most Effective for DIY Face Masks
  - <https://www.marketwatch.com/story/some-fabrics-are-more-effective-than-others-for-making-diy-face-masks-heres-which-ones-are-best-2020-04-07>
  - Includes a video by the Surgeon General on how to create a cloth face coverings and the most effective fabrics to use.
- TRAVEL GUIDELINES

When traveling, all field technicians will follow these guidelines to help ensure that they do not come contract COVID-19 while on the way to, or returning from work locations:

  - All field technicians will wear a face cloth mask while in airports, hotel lobbies, or Uber/public transportation
  - All field technicians are required to wash hands or apply hand sanitizer when entering new public transit spaces
  - Field Technicians, when possible, will maintain social distance a minimum of 6ft
  - Field Technicians are encouraged to stay in their own hotel rooms or at least keep 6ft away from each other if not possible

Sincerely,  
OSBT Management

