



Network Engineering Technologies
3140 Deming Way
Middleton, WI 53562
www.nettechnology.com

Vendor: 60426
Purchase Order: 622881-1267061-02508
Work Order: 1267061
Service ETA: 11/13/2020 11:00 AM

*Purchase Order MUST appear on all invoices and
emailed to apinbox@nettechnology.com or invoice will be
rejected, Invoice must match this Purchase Order Receipt.

Per your signed Vendor Contract, payment terms are NET 60.

Site Location Information

Customer: CVS Pharmacy
Site Number: 02508
Location: Pharmacy
253 GordonS Corner Rd.
Manalapan, NJ 07726
(732) 617-1382
Site Contact:

Technician Information

Technician Name: Sherwin Laing
Technician Phone: (908) 343-9121
Techs Manager:

Manager Phone: 4058021262

***** MUST CALL UPON ARRIVAL AND BEFORE SITE DEPARTURE *****

NET Contact Info: Please Call: 1 608 827-2270 *Your call will be handled in the order received* The following Login information is needed: your name, Company Name, work order#, callback number(mobile#)

Scheduling

1 billable technician required Arrival Time: 11/13/2020 11:00 AM

Scope of Work

CVS Photo Lab Cabling Project

NET techs will LOG IN/LOG OUT LIVE by calling (608) 827-2270. DO NOT AUTO LOG IN*

PPE requirement: Use of Face Masks or Cloth Face Covers

Upon arrival tech will need to locate the Photo Lab Switch and the Duplex or Poster Size Printer. Once all units are identified check for an available "orange" data jack between the printer location(s) and the Photo lab switch. Then check to confirm if there is an available power outlet at the printer location (s). Report findings to NET before proceeding to the next steps.

SOW: Need tech to complete cabling for POSTER SIZE PRINTER inside the photo lab.

Part 1: (Complete one of the following options)

- Option A (SURVEY/TEST: Existing run): If there is a direct cable run, tech will need test, certify the existing run. Cables will need to be jacked on both ends then patched into an available port on the photo switch.

- Option B (INTERNAL Run: switch is located within the Photo Lab): If there is no direct cable run, tech will need to run cable from printer location to the photo lab switch. Once cable is terminated and tested to spec tech will need to label new jacks as the next 600 series cable in line. Cables need to be jacked on both ends then patched into an available port on the photo switch.

- Option C (EXTERNAL Run: switch is located in the data rack): If there is no direct cable run, tech will need to run cable from printer location to the photo lab switch. Once cable is terminated and tested to spec tech will need to label new jacks as the corresponding port that was terminated



Network Engineering Technologies
3140 Deming Way
Middleton, WI 53562
www.nettechnology.com

Vendor: 60426
Purchase Order: 622881-1267061-02508
Work Order: 1267061
Service ETA: 11/13/2020 11:00 AM

*Purchase Order MUST appear on all invoices and
emailed to apinbox@nettechnology.com or invoice will be
rejected, Invoice must match this Purchase Order Receipt.

Per your signed Vendor Contract, payment terms are NET 60.

at the patch panel. Cables need to be jacked on both ends then patched into an available port on the photo switch.

Part 2: (Reconnecting Equipment)

- Connect Duplex or Poster Printer to the cable identified above in PART 1. If FUJI has not been to the site to install the new equipment, please leave patch cord in the data jack and label it as "Poster Printer" If Fuji has already installed the printer, tech will need to connect the unit and power cycle it and ask the Manager complete a test print on the unit.

Part 3: (Electrical)

- Determine if a standard power strip can be used to extend existing power. When a power strip cannot be used, run a dirty power circuit from the nearest electrical source and provide a duplex outlet at each location(s) as needed.

****NOTE:** When technicians are not qualified to install the dirty power circuit inform NET support of the need and other arrangements will be made.

- Call NET to log out

Required Materials:

- cat 5 cable
- cat 5 jacks
- cat 5 patch cables
- surface mount box
- face plate
- electrical wire
- duplex outlets
- duplex face plates
- cable tester
- cable toner
- label marker

****Photo Hub - TECH WILL NEED BLUE PLENUM CABLE AND ORANGE ORTRONICS TRACJACKS (OR-TJ5E00-23)****

****Photo Hub will typically be mounted under the front photo lab counter or near the APEX unit.**

Required Photos

- 1) Photo Hub
- 2) Labeled Jack Near Photo Lab Switch
- 3) Close up of Jack near equipment end
- 4) Overview area of Duplex Printer, if applicable
- 5) Overview of Poster Printer, if applicable
- 6) Cable test result
- 7) Picture of power outlet, if installed
- 8) Signed copy of technicians work order

Pictures must be emailed to dss@nettechnology.com, before tech is released from site. When



Network Engineering Technologies
3140 Deming Way
Middleton, WI 53562
www.nettechnology.com

Vendor: 60426
Purchase Order: 622881-1267061-02508
Work Order: 1267061
Service ETA: 11/13/2020 11:00 AM

*Purchase Order MUST appear on all invoices and
emailed to apinbox@nettechnology.com or invoice will be
rejected, Invoice must match this Purchase Order Receipt.

Per your signed Vendor Contract, payment terms are NET 60.

When sending pictures the email subject line must read "[xxxxxx]" where xxxxxx= WO ID found on Purchase Order; usually 7 digits long. ***IMPORTANT – Subject line must be enclosed in BRACKETS [] and not PARENTHESIS ().***

Resolution

Parts List. Total Parts: 4

PartName	Qty	Used	Return	Eta	Return	Returned	Responsible	Purchasor
Internal Cable Run	1	<input checked="" type="checkbox"/>			<input type="checkbox"/>	<input type="checkbox"/>		Contractor
External Cable Run	0	<input checked="" type="checkbox"/>			<input type="checkbox"/>	<input type="checkbox"/>		Contractor
Survey Fee - No Cable F	0	<input checked="" type="checkbox"/>			<input type="checkbox"/>	<input type="checkbox"/>		Contractor
Initial Trip Fee - Abort	0	<input checked="" type="checkbox"/>			<input type="checkbox"/>	<input type="checkbox"/>		Contractor

Customer - Managers Name (PRINT)

Customer - Managers Name (SIGN)

Date

Time

Technicians Name (PRINT)

Technicians Name (SIGN)

Date

Time

MANDATORY SIGN OFF OF TECHNICIAN AND CUSTOMER CONTACT MANAGER

Sign Off does not release tech from the job site. Any questions need to be directed to NET Tech Support.