



Network Engineering Technologies
3140 Deming Way
Middleton, WI 53562
www.nettechnology.com

Vendor: 60426
Purchase Order: 651182-1317471-02292
Work Order: 1317471
Service ETA: 9/16/2021 9:00 AM
*Purchase Order MUST appear on all invoices and
emailed to apinbox@nettechnology.com or invoice will be
rejected, Invoice must match this Purchase Order Receipt.

Site Location Information

Customer: CVS Pharmacy
Site Number: 02292
Location: Pharmacy
986 Main Street
Fishkill, NY 12524
(845) 896-2032
Site Contact:

Technician Information

Technician Name: Walter Arenas
Technician Phone: (201) 724-2643
Techs Manager:
Manager Phone: 4058021262

***** MUST CALL UPON ARRIVAL AND BEFORE SITE DEPARTURE *****

NET Contact Info: Please Call: 1.608.827.2270 *Your call will be handled in the order received* The following login information is needed: name, callback number (mobile), work order #.

Scheduling

1 billable technician required Arrival Time: 9/16/2021 9:00 AM

Scope of Work

CVS - Broadband Router 2021 - REVISIT FOR CABLE RUN

-150' cable run to open red jacks

NET techs will LOG IN/LOG OUT LIVE by calling (608) 827-2270. DO NOT AUTO LOG IN*
CALL CVS_ROC 888-401-4601 (from a STORE PHONE), Option 1.1 for Broadband **In order to ensure accurate onsite times, tech will need to log in with NET Support and then immediately log in with CVS ROC and vice versa. If there is more than 15min time discrepancy between the NET and CVS onsite time, we will use the login/out times provided by ROC: INC11459180 (SEPTEMBER 2021)


PPE requirement: Use of Face Masks or Cloth Face Covers

Need tech onsite to run a new cable for Broadband connection. New cable should run from Broadband modem equipment location to the store's data rack location and terminated to a new jack on the modular patch panel. Once cable is terminated and tested to spec, tech will need to label new jacks "Broadband". (i.e. 45, 46, etc)

****Data Rack - TECH WILL NEED BLUE PLENUM CABLE AND RED ORTRONICS TRACJACKS (OR-TJ5E00-00)****

After cable run is complete, tech should complete Broadband installation as follows:

1. Connect Broadband modem to new jack at location.
2. Connect port G0/2 on the Cisco 2911 Router to patch panel port as per CVS Redbook.
3. IMPORTANT- If the modem is installed in Mangers Office at data rack, Modem MUST be connected to the UPS battery backup connection. If the modem is installed at the demarc this will not apply. If no available ports on UPS, tech can plug into next available power source. If this is a Target site, UPS will be at UPS rack at CVS Rx data rack. This information will be reported to NET at log out. Take photo of modem power connection to UPS
4. Reboot modem.
5. Label modem "CVS Retail BB" and label both the modem patch cord cable (Pink) "CVS Broadband Cable", and the Modem Power Cord: "Modem Power". Labels should be affixed to the cables approximately 12-inches from the Modem side.
6. Take 4-5 required photos:
 - a. Close-up of front of modem (showing entire unit, with indicator lights)
 - b. Close-up of back of modem (showing entire unit, with patch cord connected and showing LABELS)
 - c. Close-up of G0/2 on the Cisco 2911 Router (with patch cord connected)



- DSS INSTRUCTIONS: Pictures must be emailed to dss@nettechnology.com, before tech is released from site. When sending pictures the email subject line must read "[xxxxxxx]" where xxxxxxx= WO ID found on Purchase Order; 7 digits long, starts with a 1. ***IMPORTANT – Subject line must be enclosed in BRACKETS [] and not PARENTHESIS ().***

Customer Signed Copy