



Network Engineering Technologies
3140 Deming Way
Middleton, WI 53562
www.nettechnology.com

Vendor: 60426
Purchase Order: 655237-1320771-08900
Work Order: 1320771
Service ETA: 10/6/2021 1:00 PM
*Purchase Order MUST appear on all invoices and
emailed to apinbox@nettechnology.com or invoice will be
rejected, Invoice must match this Purchase Order Receipt.

Site Location Information

Customer: CVS Pharmacy
Site Number: 08900
Location: Pharmacy
20 University Place
New York, NY 10003
(212) 260-3052
Site Contact: Store Manager Manager

Technician Information

Technician Name: Walter Arenas
Technician Phone: (201) 724-2643
Techs Manager:

Manager Phone: 4058021262

***** MUST CALL UPON ARRIVAL AND BEFORE SITE DEPARTURE *****

NET Contact Info: Please Call: 1 608 827-2283 *Your call will be handled in the order received* The following Login information is needed: your name, Company Name, work order#, callback number(mobile#)

Scheduling

1 billable technician required Arrival Time: 10/6/2021 1:00 PM

Scope of Work

CVS – Phone Cabinet [New Run] – University Debit Card Reader

NET techs will LOG IN/LOG OUT LIVE by calling (608) 827-2283. DO NOT AUTO LOG IN*

Need tech onsite to run [1] new Cat5 cable(s) for University Debit Card Reader connections as follows:

1) Cable run will be from the pharmacy near the registers near RX counter (see pharmacist for exact location) to the phone can in the manager's office. Tech will need to terminate to the 200 series port and cross connect to port [E19].

Cables will need to be tested to spec with confirmed dial tone on all lines. These connections will be used for processing University debit cards. All jacks and patch cords on both ends should be labeled with port cable is terminated to i.e. 201 would be "UDC – 201" (for Front store connection) and i.e 202 would be "UDC – 202" (for RX connection). Tech will need to leave satin phone cords connected to each jack on the sales floor. (not patch cables)

NOTE: A stand-alone debit pin pad will be attached to this phone line later once the phone line is installed.

Analog Connection - TECH WILL NEED GREY PLENUM CABLE AND BLUE ORTRONICS TRACJACKS (OR-63730003-26), SATIN PHONE CORDS (4) & BUTTSET


***Analog connection is typically in the phone cabinet located either in the Manager's Office or back demark area

***Analog runs will terminate in the phone cabinet ports 201-299 with the following cross connections:

IF TECH IS UNABLE TO RESOLVE CABLING ISSUE WITHIN 1 HR. TECH WILL PULL A NEW CABLE. TECH SHOULD ASSUME A NEW CABLE WILL NEED TO BE PULLED AND HAVE THE NECESSARY MATERIALS TO COMPLETE THE PULL ON THIS SERVICE CALL.* FAILURE TO COMPLY WITH ANY PORTION OF THIS WORK ORDER MAY RESULT IN NON-PAYMENT.*

Required Photos

- 1) New or repaired jack on equipment end showing labels
- 2) Overview of jack location
- 3) Phone Can
- 4) Cable test result
- 5) Labeled Patch Cords



Resolution